


## Expresso NOVO bike setup for non-Expresso router wireless connection

1. Enter CONFIGURATION MODE
  - Arrow down to TRY EXPRESSO and press OK (or press OK if not connected to the internet)
  - Press OK again
  - Press Menu (  ) (Blue key with Expresso Log to the left of the Ok button) and select manual mode and hit ok.
  - Type 7913
2. Screen should change and you are now in configuration mode.
3. Using the arrow keys select “Use Network”.
4. Using arrows keys select “Wireless Connection”.
5. Follow on screen instructions to select the available wireless connection.

**Note:** The following restrictions must be followed:

- SSID **MUST** be 13 characters or less, with no special characters.
  - **Must** have a Passphrase which is 13 characters or less.
  - SSID **MUST** be broadcasting
6. Once connection has been added Press back key to return to the MAIN MENU.
  7. Select “Exit Configuration Mode”

**Note:** once the wireless setting is completed **DO NOT** go back into “wireless Connection”, this will cause the bike to go back to factory default of SparkWorld2.

If you have any questions, please contact IFH Technical Support at 1-888-528-8589 x2 and or email to [support@ifholdings.com](mailto:support@ifholdings.com) .